



Design Line Preview (Cross Section)

Design Line Preview will allow Operators to see what their blade will be doing in comparison to the surface directly below them. With this information they will be able to better understand where they want the Green Vertical Guidance nail to be on their Blade. Then they can alter the Vertical Guidance in order to manipulate the blade to do what they need to finish the job.

1. Navigate to the main work screen in Earthworks
2. **Click and hold** on the Overlays button:



3. You will then see this screen below. Enable or disable Design Line Preview (Cross Section) to show what the blade will cut when using automatics:



4. Tap **Apply** to save the settings
5. The Cross Section View will now have a dotted line indicating where the blade will cut when using Automatics (Shown Below in Red)

